

October Feet Fetish Club
Sewing Room Organizer
Supply list

You can make this organizer any size you wish. We will be using Fonts from our sewing machine on some pockets and our multi cord feet to decorate the pockets if you choose fabric for the pockets.

Fabric:

- 1 3/4 yard 45" wide for front and back of organizer and hanger tabs/casing
- 1 1/4 yard 45" wide for pocket fronts. You can also use clear vinyl.
- 1 1/4 yard 45" coordinating print or solid for pocket backing/faux binding
- 2 packages of double-faced binding or
- Sewing Thread in a color to coordinate with fabrics

Stabilizer

- Medium Fusible stabilizer *or* for heavier backing- fusible batting or fusible foam.
- Medium fusible stabilizer for pockets and hang tabs. You can also use vinyl for the pocket for a see-through effect.
- 1 roll of steam a seam or similar product. We also have double sided tape at store.

To do before class:

Prepare: Steam press fabric

Cut:

- Front and Back of Organizer: 2 pieces 13" x 56"
- Pocket fronts: 5 pieces 19 1/2" x 8"
- Pocket backings/faux binding from coordinating print or solid: 5 pieces 19 1/2" x 10"
- Stabilizer Label for top of Organizer: 1 piece of solid 8" x 8", 1 piece of coordinate 10" x 10"
- Hangers: From print fabric 3 pieces 2" x 10" for tab hangers OR 1 piece 4" x 13" for casing hanger

Stabilize:

1. Fuse to the wrong side of one 13" x 56" piece of fabric and set aside. Be patient when fusing! It needs lots of steam and holding the iron in one place at least 10 seconds, then moving to the next iron position. Once you have fused from the wrong side, repeat the steam and pressing from the right side.
2. Fuse to the wrong side of the 19 1/2" x 8" pocket fronts and the 8" x 8" solid label fabric. Fuse from the wrong side with steam, then repeat from the right side. Test a piece on scraps as all irons heat differently. Use a low-medium with steam setting and press with an up and down motion, leaving the iron in one place for a few seconds. Too hot an iron and/or ironing back and forth can distort the fusing.
3. Fuse to the wrong side of the three-tab strips OR the casing hanger piece.

